

Index

A

A	20.2
Alternate Registers	AppXI.1
American CPC6128	AppXIII.6
Amplitude	7.1
AMSDOS	1.1,1.4,9.1
AMSDOS and The BIOS	19.1
Asynchronous Events	12.2

B

B	20.3
Background ROM	10.6
Bank Switching	2.6
Bank Switching Register	AppXII.6
BASIC	1.1
BIOS	1.1
BIOS:FORMAT TRACK	19.9
BIOS:GET DR STATUS	19.12
BIOS:MOVE TRACK	19.11
BIOS:READ SECTOR	19.7
BIOS:SELECT FORMAT	19.6
BIOS:SET MESSAGE	19.3
BIOS:SET RETRY COUNT	19.13
BIOS:SETUP DISC	19.4
BIOS:WRITE SECTOR	19.8
Block Graphics	AppVI.3

C

CAS CATALOG	15.159
CAS CATALOG (DISC)	15.161
CAS CHECK	15.166
CAS IN ABANDON	15.136
CAS IN ABANDON (DISC)	15.137
CAS IN CHAR	15.138
CAS IN CHAR (DISC)	15.139
CAS IN CLOSE	15.134
CAS IN CLOSE (DISC)	15.135

CAS IN DIRECT	15.140
CAS IN DIRECT (DISC)	15.141
CAS IN OPEN	15.130
CAS IN OPEN (DISC)	15.132
CAS INITIALISE	15.124
CAS NOISY	15.126
CAS OUT ABANDON	15.153
CAS OUT ABANDON (DISC)	15.154
CAS OUT CHAR	15.155
CAS OUT CHAR (DISC)	15.156
CAS OUT CLOSE	15.150
CAS OUT CLOSE (DISC)	15.151
CAS OUT DIRECT	15.157
CAS OUT DIRECT (DISC)	15.158
CAS OUT OPEN	15.146
CAS OUT OPEN (DISC)	15.148
CAS READ	15.164
CAS RESTORE MOTOR	15.129
CAS RETURN	15.142
CAS RETURN (DISC)	15.143
CAS SET SPEED	15.125
CAS START MOTOR	15.127
CAS STOP MOTOR	15.128
CAS TEST EOF	15.144
CAS TEST EOF (DISC)	15.145
CAS WRITE	15.162
Cassette Filenames	8.7
Cassette Files	8.1,8.6
Cassette Headers	8.4
Cassette Manager	1.4,8.1
Cassette Messages	8.8
Cassette Records	8.2
Cassette catalogue	8.5
Centronics Port	13.2, AppXII.8
Character Matrices	4.4
Colours	6.2
Control Codes	4.5
CPM	20.4
CRTC (6845)	AppXII.3

D

Danish Variations	AppXII.14
DIR	20.5
DISC	20.6
DISC.IN	20.7
DISC.OUT	20.8
Disc Drives	AppXII.10
Disc Filenames	9.3
Disc Headers	9.3
Disc Interface	AppXII.9
Disc ROM	AppXII.9
Disc organization	9.5
Displayed Character Set	AppVI.1
DPB	9.10
DRIVE	20.9

E

EMS file	1.7
Envelopes	7.2
Event Blocks	AppX.1
Events	11.3,12.1
ERA	20.10
Expansion Strings	AppIV.1
External Commands	10.9,20.1
External Interrupt	11.2,AppXIII.6

F

Far Call (RST 3)	2.3
Fast Ticker Blocks	AppX.3
Filling Areas	5.5
Firmware Jump (RST 5)	2.4
Foreground ROM	10.4
Frame Flyback Blocks	AppX.3
Frame Flyback Events	11.1
French Variations	AppXII.15
Function Keys	3.5,AppIV.1

G

Graphics Symbols	AppVI6
Graphics Cursor	5.2
Graphics Paper Ink	5.2
Graphics Pen Ink	5.2
Graphics VDU	1.4,5.1
Graphics Window	5.3
Graphics Write Mode	5.2
GRA ASK CURSOR	15.70
GRA CLEAR WINDOW	15.77
GRA DEFAULT	15.231
GRA FILL	15.237
GRA FROM USER	15.235
GRA GET ORIGIN	15.72
GRA GET PAPER	15.81
GRA GET PEN	15.79
GRA GET W HEIGHT	15.76
GRA GET W WIDTH	15.75
GRA INITIALISE	15.66
GRA LINE ABSOLUTE	15.86
GRA LINE RELATIVE	15.87
GRA MOVE ABSOLUTE	15.68
GRA MOVE RELATIVE	15.69
GRA PLOT ABSOLUTE	15.82
GRA PLOT RELATIVE	15.83
GRA RESET	15.67
GRA SET BACK	15.232
GRA SET FIRST	15.233
GRA SET LINE MASK	15.234
GRA SET ORIGIN	15.71
GRA SET PAPER	15.80
GRA SET PEN	15.78
GRA TEST ABSOLUTE	15.84
GRA TEST RELATIVE	15.85
GRA WIN HEIGHT	15.74
GRA WIN WIDTH	15.73
GRA WR CHAR	15.88

H

Hardware	1.2, AppXII.1
Hardware Variants	AppXII.13
High Kernel Jumpblock	17.1
HI:KL CURR SELECTION	17.8
HI:KL L ROM DISABLE	17.5
HI:KL L ROM ENABLE	17.4
HI:KL LDDR	17.12
HI:KL LDIR	17.11
HI:KL POLLSYNCHRONOUS	17.13
HI:KL PROBE ROM	17.9
HI:KL ROM DESELECT	17.10
HI:KL ROM RESTORE	17.6
HI:KL ROM SELECT	17.7
HI:KL SCAN NEEDED	17.14
HI:KL U ROM DISABLE	17.3
HI:KL U ROM ENABLE	17.2

I

Indirections	16.1
IND:GRA LINE	16.10
IND:GRA PLOT	16.8
IND:GRA TEST	16.9
IND:KM SCAN KEYS	16.17
IND:KM TEST BREAK	16.15
IND:MC WAIT PRINTER	16.16
IND:SCR MODE CLEAR	16.14
IND:SCR READ	16.12
IND:SCR WRITE	16.13
IND:TXT DRAW CURSOR	16.2
IND:TXT OUT ACTION	16.7
IND:TXT UNDRAW CURSOR	16.3
IND:TXT UNWRITE	16.5
IND:TXT WRITE CHAR	16.4
Inks	6.2, 13.2
Inks and Colours	AppV.1
Input and Output Ports	AppXII.12
Interrupt (RST 7)	2.5
Interrupt Queues	11.4
Interrupts	11.1

J

Joysticks	3.5
Jump Blocks	1.4,1.5,14.1,15.1
Jumpblock	14.1
JUMP RESTORE	15.227

K

Kernel	1.4
Kernel Block Layout	AppX.1
Key Manager	1.4
Key Translation	3.1
Key Translation Tables	AppII.1
Key numbering	AppI.1
Keyboard	3.1,AppI.1
Keyboard Port	AppXII.8
KL ADD FAST TICKER	15.195
KL ADD FRAME FLY	15.192
KL ADD TICKER	15.197
KL BANK SWITCH	15.242
KL CHOKE OFF	15.183
KL DEL FAST TICKER	15.196
KL DEL FRAME FLY	15.193
KL DEL SYNCHRONOUS	15.204
KL DEL TICKER	15.198
KL DISARM EVENT	15.211
KL DO SYNC	15.207
KL DONE SYNC	15.208
KL EVENT	15.201
KL EVENT DISABLE	15.209
KL EVENT ENABLE	15.210
KL FIND COMMAND	15.189
KL INIT BACK	15.186
KL INIT EVENT	15.199
KL LOG EXT	15.188
KL NEW FAST TICKER	15.194
KL NEW FRAME FLY	15.191
KL NEXT SYNC	15.205
KL ROM WALK	15.185

KL SYNC RESET	15.203
KL TIME PLEASE	15.212
KL TIME SET	15.213
KM ARM BREAKS	15.25
KM BREAK EVEN	15.27
KM CHAR RETURN	15.6
KM DISARM BREAK	15.26
KM EXP BUFFER	15.9
KM FLUSH	15.229
KM GET CONTROL	15.20
KM GET DELAY	15.24
KM GET EXPAND	15.8
KM GET JOYSTICK	15.14
KM GET REPEAT	15.22
KM GET SHIFT	15.18
KM GET STATE	15.13
KM GET TRANSLATE	15.16
KM INITIALISE	15.2
KM READ CHAR	15.5
KM READ KEY	15.11
KM RESET	15.3
KM SET CONTROL	15.19
KM SET DELAY	15.23
KM SET EXPAND	15.7
KM SET LOCKS	15.228
KM SET REPEAT	15.21
KM SET SHIFT	15.17
KM SET TRANSLATE	15.15
KM TEST KEY	15.12
KM WAIT CHAR	15.4
KM WAIT KEY	15.10

L

Line Graphics	AppVI.4
Low Jump (RST 1)	2.3
Low Kernel Jumpblock	18.1
LOW:EXT INTERRUPT	18.21
LOW:FAR CALL	18.11
LOW:FIRM JUMP	18.18

LOW:INTERRUPT ENTRY	18.20
LOW:KL FOR ICALL	18.16
LOW:KL LOW PCHL	18.5
LOW:KL SIDE PCHL	18.8
LOW:KL FAR PCHL	18.13
LOW:LOW JUMP	18.3
LOW:PCBC INSTRUCTION	18.6
LOW:PCDE INSTRUCTION	18.10
LOW:PCHL INSTRUCTION	18.14
LOW:RAM LAM	18.15
LOW:RESET ENTRY	18.2
LOW:SIDE CALL	18.7
LOW:USER RESTART	18.19

M

Machine Pack	1.4,13.1
Memory	AppXII.1
Memory Map	2.1
MC BOOT PROGRAM	15.214
MC BUSY PRINTER	15.224
MC CLEAR INKS	15.220
MC PRINT CHAR	15.223
MC PRINT TRANSLATION	15.240
MC RESET PRINTER	15.222
MC SCREEN OFFSET	15.219
MC SEND PRINTER	15.225
MC SET INKS	15.221
MC SET MODE	15.218
MC SOUND REGISTER	15.226
MC START PROGRAM	15.216
MC WAIT FLYBACK	15.217

N

Non Maskable Interrupt	11.3
------------------------	------

P

PPI (8255)	AppXII.7
Palette Memory	AppXII.5
Palette Pointer	AppXII.5
Patching Jumpblocks	1.8
Printer	13.3
Processor	AppXII.1
Programmable Sound	AppIX.1

R

RAM	2.5,AppXII.1
RAM LAM	2.4
REN	20.11
Repeating Keys	AppIII.1
Reset (RST 0)	2.4
Resident System Extensions	10.1,10.7
ROM	10.1,AppII.1,2.2
RS232c	AppXII.11
RST 0 (Reset)	2.4
RST 1 (Low Jump)	2.3
RST 2 (Side Call)	2.3
RST 3 (Far Call)	2.3
RST 4 (RAM LAM)	2.4
RST 5 (Firmware Jump)	2.4
RST 6 (User Restart)	2.4
RST 7 (Interrupt)	2.5
RSX Parameter Examples	10.10
RSXs	10.1

S

SCR ACCESS	15.120
SCR CHAR INVERT	15.115
SCR CHAR LIMITS	15.97
SCR CHAR POSITION	15.98
SCR CLEAR	15.96
SCR DOT POSITION	15.99
SCR FILL BOX	15.113

SCR FLOOD BOX	15.114
SCR GET BORDER	15.110
SCR GET FLASHING	15.112
SCR GET INK	15.108
SCR GET LOCATION	15.93
SCR GET MODE	15.95
SCR HORIZONTAL	15.122
SCR HW ROLL	15.116
SCR INITIALISE	15.98
SCR INK DECODE	15.106
SCR INK ENCODE	15.105
SCR NEXT BYTE	15.101
SCR NEXT LINE	15.103
SCR PIXELS	15.121
SCR PREV BYTE	15.102
SCR PREV LINE	15.104
SCR REPACK	15.119
SCR RESET	15.90
SCR SET BASE	15.92
SCR SET BORDER	15.109
SCR SET FLASHING	15.111
SCR SET INK	15.107
SCR SET MODE	15.94
SCR SET OFFSET	15.91
SCR SET POSITION	15.239
SCR SW ROLL	15.117
SCR UNPACK	15.118
SCR VERTICAL	15.123
Screen	13.1
Screen Memory Map	6.3
Screen Modes	6.1
Screen Pack	1.4,6.1
Serial Interface	AppXII.11
Side Call (RST 2)	2.3
Soft EOF	AppXIII.1
Sound	13.2
Sound Chip (AY 3 8910)	AppXII.3
Sound Manager	1.4,7.1
Sound Queues	7.4

Sound Synchronisation	7.5
SOUND A ADDRESS	15.181
SOUND AMPL ENVELOPE	15.176
SOUND ARM EVENT	15.172
SOUND CHECK	15.171
SOUND CONTINUE	15.175
SOUND HOLD	15.174
SOUND QUEUE	15.169
SOUND RELEASE	15.173
SOUND RESET	15.168
SOUND T ADDRESS	15.182
SOUND TONE ENVELOPE	15.179
Spanish Variations	AppXII.13
Stack	2.5
Streams	4.1
Synchronous Events	12.2

T

Text Cursor	4.3
Text Paper Ink	4.2
Text Pen Ink	4.2
Text Streams	4.1
Text VDU	1.4,4.1
Text VDU Control Codes	AppVII.1
Text Windows	4.2
Ticker Blocks	AppX.2
Tickers	11.1
Tone Periods	7.1,AppVIII.1
TAPE	20.12
TAPE.IN	20.13
TAPE.OUT	20.14
TXT ASK STATE	15.230
TXT CLEAR WINDOW	15.38
TXT CUR DISABLE	15.44
TXT CUR ENABLE	15.43
TXT CUR OFF	15.46
TXT CUR ON	15.45
TXT GET BACK	15.57

TXT GET CONTROLS	15.63
TXT GET CURSOR	15.42
TXT GET M TABLE	15.62
TXT GET MATRIX	15.58
TXT GET PAPER	15.54
TXT GET PEN	15.52
TXT GET WINDOW	15.37
TXT INITIALISE	15.28
TXT INVERSE	15.55
TXT OUTPUT	15.32
TXT PLACE CURSOR	15.49
TXT RD CHAR	15.34
TXT REMOVE CURSOR	15.50
TXT RESET	15.29
TXT SET BACK	15.56
TXT SET COLUMN	15.39
TXT SET CURSOR	15.41
TXT SET GRAPHIC	15.35
TXT SET M TABLE	15.60
TXT SET MATRIX	15.59
TXT SET PAPER	15.53
TXT SET PEN	15.51
TXT SET ROW	15.40
TXT STR SELECT	15.64
TXT SWAP STREAMS	15.65
TXT VALIDATE	15.47
TXT VDU DISABLE	15.31
TXT VDU ENABLE	15.30
TXT WIN ENABLE	15.36
TXT WR CHAR	15.33

U

Upper ROM	2.6
USER	20.15
User Restart (RST 6)	2.4

V

Video Gate Array	AppXII.4
VDU screen Memory	AppXII.2

Z

Z80 Alternate registers	1.6
Z80 Flags	1.6
Z80 Restarts	1.6